

USER'S MANUAL



On-Grid PV Inverter

Series: RITxK(x=5,6,8,10,15,20,30,40,50,60)

USERS MANUAL

INSTALLATION, OPERATION AND REPAIR MANUAL

About Rotosol

Rotosol solar (Division of Rotomag Motors and Controls Pvt. Ltd., located Near Anand, Gujarat, India ., which is specialized in manufacturing of solar PV inverters.

Rotosol is dedicated to providing perfect power conversion and control solutions for solar power generation installations , manufacturing and marketing of solar PV inverters. Rotosol possesses the first-class production equipment . Rotosol provide all kinds of high-quality and reliable grid-connected solar inverters and energy system solutions to satisfy the consistently increasing demands for global energy.

The newly designed PV Inverter features itself with full load high efficiency, high reliability and user-friendly interface. The maximum conversion efficiency of our inverter is up to 98%. A user-friendly installation & interface, professional industrial design, and design for reliability mechanism, give the Inverter Family a competitive edge for customers from all regions.

As a customer-oriented company, Rotosol is always trying to improve product and enhance customer satisfaction. High quality with customer satisfaction is the Goal of Rotosol , not just in product quality control, but also in quality of service and support. Rotosol is able to help customers reduce energy consumption and carbon dioxide emissions by leading green solutions.



CONTENTS

1. About This manual	4
1.1 Scope of Validity	4
1.2 Target Group	4
1.3 Additional Information	4
2 Safety Instructions	5
2.1 Safety Precautions	5
2.2 Explanations of Symbols	6
3 Unpacking	7
3.1 Assembly Parts	7
3.2 Identifying the Inverter	8
4 Mounting	9
4.1 Safety	9
4.2 Selecting the Appropriate Mounting Location	9
4.3 Mounting the Inverter with Wall Mounting Bracket	11
5 Electrical Connection	12
Notes:	12
5.1 Overview of the Connection Area	13
The following figures show the assignment of the individual connection areas on the bottom of the Inverter	13
5.2 Connection to the Public Grid (AC)	13
5.3 Connection to the PV Generator (DC)	16
6 System Diagram	21
7 Operation	23
7.1 Overview of Control and Displays	23
7.2 Commissioning	24
7.3 LED Display	24
7.4 LCD Display	25
8 Trouble Shooting	30
9 Inverter Inspection and Repair	34
9.1 LCD cannot Display	34
9.2 LCD display Fault Codes	34
9.3 Repeat Countdown, cannot generation	35
9.4 AC circuit breaker trip	35
9.5 Monitoring Fault	35
9.6 Problem During Inverter Generation	35
9.7 Power Components Inspection (without DC power supply)	36
9.8 MOSFET Driver Inspection (for 5th generation models)	41
9.9 Inverter Frequently Tripping Due to Grid Fluctuation	41
10 Contact	43
Annex Warranty Terms (Overseas)	43

1. About This manual

1.1 Scope of Validity

This manual describes the installation, commissioning, operation and maintenance of the following on-grid PV inverters produced by Rotosol:

Commercial Systems & Power Plants 5-60KW

RIT5K, RIT6K, RIT8K, RIT10K, RIT15K, RIT20K, RIT30K, RIT40K, RIT50K, RIT60K

Please keep this manual all time available in case of emergency.

1.2 Target Group

This manual is for qualified personnel. The tasks described in this manual must only be performed by qualified personnel.

1.3 Additional Information

For more information please go through the website www.rotosol.solar

2 Safety Instructions

2.1 Safety Precautions

1. All work on the inverter must be carried out by qualified electricians and ensure that children can not access to the equipment.
2. The device may only be operated with PV generators. Do not connect any other sources of energy to the device.
3. This PV generator and inverter must be connected to the ground in order to reach maximum protection for property and persons.
4. Do not touch cover until 3 minutes after disconnecting all sources of supply. This is because the charge stored in capacitors may result a risk of electric shock.
5. The enclosure of Inverter can become hot during operation. To reduce the risk of injury, do not touch the cover, heat sink at the back of the PV-Inverter or nearby surfaces while Inverter is operating.
6. Do not use the equipment for purposes other than those described in this manual.
7. Both the inverter and associated transport packaging are mainly made of recyclable raw materials. Please ensure that the used device and any relevant accessories are disposed of in accordance with applicable regulations.
8. Packed with damping EPE and carton, Rotosol inverter should be placed upwards and handled with care in delivery. Pay attention to waterproof.
9. Alternative uses, modifications to the inverter not recommended by Rotosol or the installation of components not sold by Rotosol void the warranty claims.

2.2 Explanations of Symbols


Symbol	Explanation
	Danger of Electric Shock. The inverter is directly connected with the public grid. All work on the inverter must be carried out by qualified personnel only.
	Beware of hot surface. The inverter can become hot during operation. Do not contact the device during operation.
	Caution, risk of electric shock Energy storage timed discharge, time to be indicated adjacent to the symbol.
	Caution, Danger. This device directly connected with electricity generators and public grid.
	Do not dispose of this device with the normal domestic waste.
	Without Transformer. This inverter does not use transformer for the isolation function.
	CE mark. The inverter complies with the requirements of the applicable EC guidelines.
	Regulatory compliance mark. The inverter complies with the requirements of Australian Communications Authority guidelines, safety and EMC guidelines.
	Notes, Important. Non-adherence to these instructions may adversely affect the operating convenience or functionality of the device.
	Refer to manual before service.

3 Unpacking

3.1 Assembly Parts

Please check the delivery for completeness and any visible external damage. Contact your dealer at once if anything is damaged or missing.

Assembly parts are as listed below:



Object	Quantity	Description	Object	Quantity	Description
A	1	Solar inverter	B	1	Wall mounting bracket
C	1	User manual	D	1	Certificate of inspection
E	1	Installation diagram	F	1	Notice for installation
G	1	Warranty card	H	1	RV5.5-6 terminal
I	3	Plastic Expansion Tube	J	3	Tapping screw
K	1	Security screw	L	1	Screwdriver for security screw
M	2sets	DC plug connector	N	4	Screw
O	1	Waterproof Junction Box	P	4	Terminal

3.2 Identifying the Inverter

You can identify the inverter by the type label. Information such as serial number (Serial No.) and model name of the inverter, as well as the device's technical parameters are specified on the type label. The type label is on the right side of the enclosure.

4 Mounting

4.1 Safety

DANGER!

Danger to life due to potential fire or electric shock.

Do not install the inverter near any inflammable or explosive items. The inverter will be directly connected with high voltage power generation device. The installation must be performed by qualified personnel only in compliance with national or local standards and regulations.

CAUTION!

Danger of burn injuries due to hot enclosure parts.

• Install the inverter so that it cannot be touched inadvertently.

Risk of injury due to the heavy weight of the inverter.

• Take the inverter's weight into account for mounting. (Weight of inverter refers to chapter 8.)


4.2 Selecting the Appropriate Mounting Location

Consider the following points when selecting where to install:

- The mounting method and location must be suitable for the inverter's weight and dimensions.
- The inverter must be installed in the solid walls ,such as brick walls or concrete walls in case of vibration noise or inverter falling off.
- The installation site should be clearly visible and can be safely into without aids such as scaffold.
- For the convenience of checking the LCD display and possible maintenance activities, please install the inverter at eye level.
- The altitude of installation site should be below 2000m,more than 2000m above the sea level will cause derating.
- The ambient temperature of installation site should be between -20 °C and +55 °C (between -4 °F and 131 °F).
- Install the inverter directly exposing to strong sunshine is not recommended, the excess heating


might lead to power reduction.

- Leave enough effective space around the inverter for better ventilation.




- Vertical installation, wiring area must be downside, lateral installation is not allowed; in backward tilted installation, tilt angle should not exceed 30 degrees; Forward tilted, horizontal or inverted installation is not allowed.


4.3 Mounting the Inverter with Wall Mounting Bracket



1. Use the wall mounting bracket mark the drilling position and drill the holes for the screws.
2. Fix the wall mounting bracket with the equipped self-tapping screw.



3. Hang the inverter to the mounting bracket and ensure the slot is fitted on the bracket.
4. Check to ensure the inverter is correctly seated. Make sure to lock it with the security screws. (See the figure below.)




5 Electrical Connection

Notes:

1. Electrical installation & maintenance shall be conducted by licensed electrician and shall comply with local Wiring Rules.
2. After the inverter has been installed in its fixed position, the electrical connection to the unit can be established.
3. Make sure Max. Open Voltage and short-circuit current of the each PV strings accord with the Spec.
4. Choose the appropriate cable width for AC/DC wire. The cross sectional area of DC input conductor lead should be 4mm^2 PV wire, that of AC output conductor should also be 4mm^2 cooper wire, and that of external ground conductor should be 4mm^2 cooper wire.
5. On both sides of inverter to the grid and PV array, there must be between circuit breaker and surge protector, and during inverter electrical connections, circuit breakers on both sides should be disconnected to prevent electric shock.
6. To connect the inverter, the AC and DC sides must be disconnected from all power sources and secured against being inadvertently swithced back on.
7. Before connecting the inverter to PV arrays and public grid, make sure the polarity is correct.

5.1 Overview of the Connection Area

The following figures show the assignment of the individual connection areas on the bottom of the inverter.



Object	Description
a	DC connectors (+) for connecting the PV strings
b	DC connectors (-) for connecting the PV strings
c	WiFi/RS485 Communication Waterproof Connector
d	Waterproof Junction Box, AC connection
e	DC Switch

5.2 Connection to the Public Grid (AC)

5.2.1 Conditions for Connection

CAUTION!

Unit Disconnection From Load

Disconnect the circuit breakers and switches of inverters AC and DC sides.

5.2.2 Connection to Public Grid (AC)

Measure the grid voltage to make sure within the permissible range. Disconnect the circuit breaker between the inverter and the grid.

1. Disconnect the DC and AC breaker, DC switch in the "OFF" state..



2. Disconnect the DC and AC breaker, DC switch in the "OFF" state.




3. Assembly yellow-green Ground wire RV5.5-6 terminal, and connect to one ground terminal.




4. Prepare AC cable ($\Phi 4\text{mm}^2$ or bigger) , stripping length is $14\pm 0.5\text{mm}$. Connect the cable with terminals.



5. Run the cable harness with the pressed terminals through the junction box and insert the black cable harness, L1, L2 and L3 into the caps of N, W, V and U as shown in the system connection diagram. Tighten the screws.



6. Close junction box and tight the screws



5.3 Connection to the PV Generator (DC)

CAUTION!

Unit Disconnection From Load

Disconnect circuit breakers and switches on both AC and DC sides

5.3.1 Conditions for the DC Connection

The connected PV modules must meet following requirements

- Same type
- Same model
- Identical alignment
- Identical tilt

The following limit values at the DC input of the inverter must not be exceeded (connecting to a higher

voltage will destroy the device):


Type	Maximum input voltage [Vd.c]	Maximum input current [Ad.c]
RIT5K	1000	11x2
RIT6K	1000	11x2
RIT8K	1000	11x2
RIT10K	1000	11x2
RIT15K	1000	22+11
RIT20K	1000	22x2
RIT30K	1000	33x2
RIT40K	1000	40x2
RIT50K	1000	36x3
RIT60K	1000	40x3

5.3.2 Assembling the DC Plug Connector

In order to connect to the inverter, all connection cables of the PV modules must be equipped with the DC plug connectors provided. You will find the necessary DC plug connector for DC connection in the package. To assemble the DC plug connectors, proceed as detailed below. Ensure the plug connectors have the correct polarity.

The plug connector in DC side includes male and female as blow.

Please note that the sizes of metal connecting tubes are different. The bigger one is for female connector and the smaller one is for male connector.




Assembly Instructions:

- ◆ Prepare the DC wire to connect the positive and negative DC arrays. Stripping length is 12~15mm, sectional area is 4 mm² as below.




- ◆ Insert the DC wire to metal connecting tube. Make sure all line heads are in the connecting tube as picture blow.



- ◆ Use crimping pliers to fasten the metal connecting tube and copper wire. Make sure the harness will not

fall off, see picture below.



◆ Insert the assembled cable into male/female connector. A "chick" sound can be heard when connecting correctly. Then tighten the cap. Refer to the picture below.



5.3.3 Connecting the PV Generator (DC)

DANGER!

Danger to life due to high voltage in the inverter.

- Before connecting the PV generator, ensure that the AC&DC circuit breaker is switched off.


Notes:

1. Make sure that you have disconnected circuit breakers and switches on both DC and AC sides.
2. Check the connection cables of the PV modules for correct polarity and that the maximum input voltage of the inverter is not exceeded.
3. Check the DC plug connector for correct polarity and well connected.

Plug the DC plug connectors into DC terminals on Inverter.




The inverter DC input is equipped with two groups(DC-A and DC-B) of connecting sockets for DC input , and each group contains two pairs of connecting sockets (DC+ and DC-). Make sure at least one pair of DC terminal in each group is connected with PV array in installation,and group A and B must be connected with two arrays separately but not with one array,see picture below.



6 System Diagram

The typical connection diagram for the entire PV system is shown in the following figure.



Note:

- QF1、QF2 : DC Breaker
- QF3 : AC Breaker
- SPD : Surge Protector

1. PV Panel: Provide DC power to inverter
2. Inverters: Converts DC (Direct Current) power from PV panel(s) to AC (Alternating Current) power. Because Inverter is grid-connected, it controls the current amplitude according to the PV Panel power supply. Inverter always tries to convert the maximum power from the PV array.
3. QF1/QF2 Breaker: The current per DC string does not exceed 25A.
4. QF3 Breaker: Refer to the following table to choose the AC breaker.

Refer to the following table to choose the AC breaker.

Type	Max AC Current [A]	Rate current of AC breaker[A]
RIT5K	8.5	16
RIT6K	10.5	16
RIT8K	13.5	20

RIT10K	17	25
RIT15K	27	32
RIT20K	32	40
RIT30K	45	63
RIT40K	60	100
RIT50K	75	100
RIT60K	90	125

5. LPS: Lightning protection system, refer to the following options:

AC side, nominal discharge current 20KA, second grade lightning protection, protection voltage 2.5KV

DC side, nominal discharge current 20KA, second grade lightning protection, protection voltage 3.2KV

6. The wiring distance between the inverter and the distribution box should be at least 5 meters.


7. Utility: Referred to as "grid" in this manual, i.e. the media your electric power company provides power to your place. Please note that Inverter can only be connected to low-voltage systems (namely, 220/230Vac, 50/60Hz).

7 Operation

Product Overview



7.1 Overview of Control and Displays



There are four function keys on the front panel: UP, DOWN, ESC, ENT. The keypad is used for:
Up and Down keys: Scrolling the displayed parameter, or modify the adjustable parameters; Esc and Ent keys: Cancel or Enter.

7.2 Commissioning

After completing of the mechanical and electrical installation, the inverter could be put into operation.

1. Switch off DC and AC side circuit breakers and switches.
2. Wait until the screen is on and set up grid connection standard. (Please refer to 7.4.1 for specific operations)
3. The inverter starts up and feed into the utility grid automatically when all the necessary conditions of normal operation for the inverter is fulfilled.
4. Check whether the display and LEDs are indicating a normal operating state.

Sign	Color	Instructions
POWER	Green	On: Power On
COM	Green	On: Normal Operations and Feed the utility grid.
FAULT	Red	Flash: Check wiring

7.3 LED Display

Three LED lights are assembled on the inverter, **COM, POWER, FAULT**. When DC and AC power are normal and the inverters starts up, the POWER LED turns on. When the inverter is operating and feed electricity into the utility grid normally, the COM LED turns on. When there is faulty in the PV System or inverter, the FAULT LED flashes, and the faulty code will be shown on LCD Screen.

POWER LED (Green)

POWER LED turns on when DC voltage reaches the start-up voltage and turns off when it falls below a certain value. POWER LED is on represents inverter is active and so is the inverter control system. If POWER LED is off, inverter cannot be normally started up.

Under normal operation conditions, when light is sufficient, inverter connects to the grid and generates in the morning and stops after dark. This procedure may repeat several times in one day, especially in morning and at night. It is a normal working phenomenon but not a wrong signal.

COM LED (Green)

The COM LED turns on when the inverter start feed electricity into grid. And the COM LED is off when the inverter is standby.

FAULT LED (Red)

Red FAULT LED turns on means the on-grid generation is stopped due to some faults. Please wait 10

minutes to be sure whether the fault is temporary. If yes, inverter will automatically restart again. If not, contact after-sales personnel.


7.4 LCD Display

Inverter will start up automatically with enough DC voltage provided by PV array. When starting up (POWER LED is on), it shows "Rotosol" on LCD in front of the inverter.



Rotosol Inverter

The inverter will delay 1 second and automatically jump to the System Checking Interface.




System Checking

> > >

7.4.1 First Boot Setting

First turned on power, the inverter will delay 1 second and automatically jump to the reminder interface to set country.



Please Choose
Your Country

Press Ent to country and standard setting interface. Press UP and DOWN to show countries. Choose corresponding country and standard and press Ent. **For example installed in India, please choose**



IND INDIA

Country setting completed, system will automatically jump to the reminder interface to set time.

Please Set
Day & Time

Press Ent to time setting interface. Press UP and DOWN to adjust number and press Ent. Set year, month, day, hour, minute and second one by one according to local time.

Date Dd-Mm-2015
Time Hh-Mm-Ss

7.4.2 Main Interface

When time setting is completed, press Ent to exit and system will enter into the main interface as below. The LCD will automatically enter into the main interface after system checking when the inverter starts up next time. Operation status and generation information of inverter will be show on the main interface (Display Info),the current time will be shown in the last line.

Power:5.1KW
Vpv1:230.1V

Generation information interface scrolls every 3 seconds. Up and Down also can be used to select.

Items of generation information are as follows:

Display	Description
Power	Current Output Power
IPV1/IPV2	DC Input Current in MPPT One/Two
VPV1 /VPV2	DC Input Voltage in MPPT One/Two
BUS+/BUS-	Voltage of BUS+/BUS-
Ia/Ib/Ic	AC output Current per phase
Ua/Ub/Uc	AC output Voltage per phase
FAC	AC Output Frequency

Etoday	Total Generation Capacity today
Etotal	Total Generation Capacity
ETPV1/ETPV2	Total Generation Capacity today in MPPT One/Two
RunTim	Total Running Time Today
SumTim	Total Running Time


7.4.3 Query Interface

Press Ent on main interface to view related information in query interface. Eight choosing items on the query interface: System Info,Error Record,SET,Clear Record,Data & Time SER,RS485 Address,SN Number,GridpowerCtrl. Press UP and DOWN to select the query item,press Ent to get in and Esc back to main interface.



System Info

System Information shows country standard and operation parameters.




UP and DOWN could be used to show the items of System info as follows:

Display	Description
Standard	Country and standard setting
Case_Temp	Chasis temperature
ModleTemp	Power module temperature
Screenwriter	LCD temperature
Rated Power	Inverter rated output power
PG1Imp	The insulation resistance of positive pole in PV1
NG1Imp	The insulation resistance of negative pole in PV1
PG2Imp	The insulation resistance of Positive pole in PV2

Error Record

In Error Record, it shows fault series number, the time fault happens, faulty code and error display. When fault happens, FAULT LED turns on. "Trouble Shooting" in Chapter 9 is for users to refer to investigate and solve the faults. Please contact after-sales if the problem still exists.




Nub/Total:X/XXX
E:XXXXX

Error Record Shows:

Display	Description
Nub/Total	Fault sequence/Total faults number
E	Fault Code
ST	Fault starting time
ET	Fault Ending Time

SET

Reset the inverter parameters by selecting SET. Passwords are needed for the setting. Which only can be



PassWord:
XXXX

operated by after sales personnel to make sure the safety and normal operations of the inverter.

Clear Record

Clear inverter's Error Record and Run records. Passwords are needed for the setting, which only can be

operated by after sales personnel to make sure the safety and normal operation of the inverter.




Date & Time SET

Press Ent to Date and Time setting interface. Press UP and DOWN to adjust number and press ESC go to next step. Set year, month, day, hour and minute one by one according to local time. Press ENT save and back to main interface.

RS485 Setting

485 address shows communication address and baud rate. Press ENT to enter communication address setting interface; press UP and DOWN to change values; Press ENT to confirm.



SN It shows inverter's serial Number

SetPowerCtrl

This item is for setting grid-connecting power limitation. Press ENT to enter control selection interface. Press UP and DOWN to choose start-up or use forbidden, then press ENT to confirm; Press ENT to enter power limitation setting interface. Press UP and DOWN to set limitation value, then press ENT to confirm.



7.4.4 LCD Back light Control

The back light of LCD will automatically turn off after 5 minutes, and LCD will automatically turn off after 10 minutes to saving-electricity mode. Press any key to turn on the LCD.

8 Trouble Shooting

In most situations, the inverter requires very little service. However, if inverter is not able to work perfectly, we recommend the following solutions for quick troubleshooting.

Error display	Possible causes	Corresponding measures
EepromErr	1.Unstable PV Input voltage 2. Machine Failure	1.After PV input voltage is stabilized, the machine will automatically restart. 2. Please contact with local dealer if error remains the same after several reset.
GFCI.Err	1.PV(+) or PV(-) earthing 2.Machine Failure	1.Check PV(+) and PV(-)ground impedance, make sure impedance is more than 2M Q. 2.Please contact with local dealer if error remains the same after several reset.
GridF.OutLim	Electricity grid fluctuations Electricity grid Frequency out of range Machine failure	1. After electricity grid returns to normal,the machine will automatically restart. 2.Please contact with local dealer if error remains the same after several reset.
GridV.OutLim	1. Off Phase 2.Electricity grid Phase/line voltage overload 3.electricity grid Voltage unbalance	1.Disconnect the input/output switch, check the AC-side wiring and reset the plug to rule out bad contact 2.After electricity grid returns to normal, the machine will automatically restart. 3.Please contact with local dealer if error remains the same after several reset.
IntFaultA	Machine failure	Please contact with local dealer if error remains the same after several reset.
IntFaultB	1.PV input voltage is too high	1..Adjust the panel configuration to lower the input voltage.
	2.Electricity grid abnormal	2.After electricity grid returns to normal, the machine will automatically restart.
	3.Bus hardware overvoltage fault	3.Please contact with local dealer if error remains the same after several reset.
IntFaultC	Electricity grid abnormal	1.After electricity grid returns to normal, the machine will

	Unbalanced current fault	automatically restart. 2.Please contact with local dealer if error remains the same after several reset.
IntFaultD	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Software over current fault	2.Please contact with local dealer if error remains the same after several reset.
IntFaultE	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Hardware over current fault	2.Please contact with local dealer if error remains the same after several reset.
IntFaultG	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.DCI too high	2.Please contact with local dealer if error remains the same after several reset.
IntFaultJ	Relay failure	Please contact with local dealer if error remains the same after several reset.
IntFaultK	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Bus differential fault	2.Please contact with local dealer if error remains the same after several reset.
IntFaultL	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Low Bus voltage fault	2.Please contact with local dealer if error remains the same after several reset.
IntFaultM	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.High Bus voltage fault	2.Please contact with local dealer if error remains the same after several res
IntFaultN	Internal hardware fault	Please contact with local dealer if error remains the same after several reset.
IntProtectA	Offset current protection	Please contact with local dealer if error remains the same after several reset.
IntProtectB	Relay protection	Please contact with local dealer if error remains the same after several reset.
IntProtectC	Over current protection	Please contact with local dealer if error remains the same after several reset.

IntProtectD	1.PVside high current	1.Adjust the panel configuration to lower the input current.
	2.Boost over current protection	2.Please contact with local dealer if error remains the same after several reset.
IntProtectE	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Soft start overtime protection	2.Please contact with local dealer if error remains the same after several reset.
IntProtectF	When direct current is at low	Please contact with local dealer if error remains the same after several reset.
	voltage, Soft start overtime protection.	
IntProtectG	Bus voltage differential protection	Please contact with local dealer if error remains the same after several reset.
IntProtectH	Low Bus voltage protection	Please contact with local dealer if error remains the same after several reset.
IntProtectI	High Bus voltage protection	Please contact with local dealer if error remains the same after several reset.
IntProtectJ	Inverter bridge protection	Please contact with local dealer if error remains the same after several reset.
IntProtectK	Bus hardware overvoltage	Please contact with local dealer if error remains the same after several reset.
	protection	
IntProtectL	Power module protection	Please contact with local dealer if error remains the same after several reset.
IntProtectM	1.electricity grid unbalance	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Unbalanced current protection	2.Please contact with local dealer if error remains the same after several reset.
IntProtectN	1.Electricity grid abnormal	1.After electricity grid returns to normal, the machine will automatically restart.
	2.Hardware	

	overcurrentprotection	2.Please contact with local dealer if error remains the same after several reset.
IntProtectO	MCU protection	Please contact with local dealer if error remains the same after several reset.
IntProtectP	Frequency fault protection	Reset grid frequency in accordance to local grid standard
IntProtectQ	DCI too high protection	Please contact with local dealer if error remains the same after several reset.
IntProtectR	DCI offset protection	Please contact with local dealer if error remains the same after several reset.
IntProtectS	Voltage offset protection	Please contact with local dealer if error remains the same after several reset.
IntProtectT	PV over current protection	Please contact with local dealer if error remains the same after several reset.
IntProtectU	Internal hardware abnormal protection	Please contact with local dealer if error remains the same after several reset.
IsolationErr	1.PV(+) or PV(-) earthing 2.Lightening 3.Machine failure	1.Check PV(+) and PV(-) ground impedance, make sure impedance is more than 2MQ. 2.Please contact with after-sales if error remains the same after several reset.
PV. Reverse	1.PV polarity reverse protection	1.Turn off input/output switch,check if pv polarity is correct or
	2.Machine failure	not, for troubleshooting. 2.Please contact with after-sales if error remains the same after
PVVoltOver	PV The input voltage is too high	1. Adjust the panel configuration to lower the input voltage. 2.Please contact with local dealer if error remains the same after several reset.
SPICommErr	SPI communication error	Please contact with local dealer if error remains the same after several reset.
TempOver	1.The machine is exposed to sun.	1. Lower machine surrounding temperature or move it to a lower
	2.the ambient temperature is too	temperature place.

	high	2. Remove foreign matter.
	3. The heat sink or fan blocked by foreign matter	3. Please contact with local dealer if error remains the same after several reset.
	4. Machine failure	
TempSensorErr	Abnormal temperature sensor	Please contact with local dealer if error remains the same after several reset.
ExtFanErr	1. Fan blocked by foreign matter	1. Remove foreign matter.
	2. Machine failure	2. Please contact with local dealer if error remains the same after several reset.
IntFanErr	Internal fan fault	Please contact with after-sales if error remains the same after several reset.

- Restart: Disconnect input and output switches in order, reconnect them after LCD and indicating lights go off.
- If there is no display on the LCD, please check both AC and DC wiring.
- If the input DC voltage is higher than start up voltage, the inverter still doesn't work, please call local service.
- If it is intended to replace the cable or open the enclosure lid, please call our service.
- Under the low light conditions, the inverter may continuously start up and shut down. It is due to insufficient power generated to operate the control circuits.

9 Inverter Inspection and Repair

9.1 LCD cannot Display

- check DC wiring is ok.
- PV array's '+' and '-' is right connect with inverter's DC input connector;
- check DC switch is at 'ON' position;
- check PV array's voltage within right range by use multi meter.

9.2 LCD display Fault Codes

9.2.1 Grid Fault

- check safety code or country code is correct (all of the models provide to Rotomag is India);
- check grid's voltage and frequency is within setting range (for the place where the real range is out of setting, please contact us for detailed setting);

c. check all of AC wiring connection point is well connected.

9.2.2 Isolation Fault

Check PV array have leak current.

9.2.3 Input DC bus voltage High

9.2.3.1 check DC input voltage is within inverter's input range;

9.2.3.2 check all of AC wiring connection point is well connected.

9.3 Repeat Countdown, cannot generation

9.3.1 check the resistance between PV(+) and ground, PV(-) and ground bigger than 2M Ω ;

9.3.2 check PV array's output voltage is correct.

9.4 AC circuit breaker trip

9.4.1 check circuit breaker's capacity is suitable with inverter's maximum output power;

9.4.2 for the system installed with leak current sensor circuit breaker,

a. trip during cloudy /rainy day, change with higher capacity of current sensor breaker;

b. check if the PV panel's frame is too close with ground or roof, exit the leakage current;

c. check if the PV DC wiring have the leakage current.

9.5 Monitoring Fault

9.5.1 cannot search wifi signal of inverter,

before open the cover of monitoring card, please make sure the inverter is generation;

a. check the cable wiring is well connected;

b. the LED on the monitoring card is flash;

c. Measure the voltage of signal cable is correct(DC 5V)

9.5.2 WIFI cannot upload data

connect inverter's WIFI with smart-phone, and go to 10.10.100.254 website via smart-phone's explorer.

a. check if the inverter's WIFI card have been assigned IP address;

b. check the inverter's power generation date or serial information displayed through the web page.

c. check the WIFI signal is strong enough.

9.6 Problem During Inverter Generation

9.6.1 Power generation lower than expect

a. check if the panel surface need to be clean;

b. check if the panel have shading problem;

c. check all of the DC wiring is well connected;

d. check if the wiring connection point have been oxidized;

e. check the cable used for DC and AC is right size, and the length of the cable not excess the recommend length.

9.6.2 Generation difference between two or among three MPPT channels.

- a. check each MPPT channels' input voltage not higher than 30%;
- b. check PV array's tilt and azimuth angle is the same;
- c. check if the PV array have shading problem.

9.6.3(Grid line Voltage Fault) Fault Report

- a. due to the grid fluctuate, if the fault report occasionally, you can ignore this fault report, and the inverter could recover automatically after the grid back to the normal;
- b. if this fault frequently report, we recommend to upgrade the firmware of DSP.

9.6.4 E17(Grid Voltage Fault) Fault Report

- a. check the safety/country code is correct;
- b. check all of the AC wiring point is well connected;
- c. measure the AC voltage is within normal range;
- d. re-setting the AC output range(maximum volt. Is 519Vac).

9.6.5 E29(M Grid Freq Fault) Fault Report

- a. check the safety/country code is correct;
- b. check all of the AC wiring point is well connected;
- c. measure the AC frequency is within normal range;
- d. re-setting the AC frequency range(49.0 ~ 51.0Hz).

9.6.6 Other Fault Report

9.6.6.1 Inverter report the same Fault Code during the same time of the day

Check if the AC output point nearby have the big power load. When the load start, the grid voltage or frequency will be affect.

9.6.6.2 Inverter report over current or over voltage fault code

- a. check the cable used for DC and AC is right size, and the length of the cable not excess the recommend length;
- b. check local load consumption is low, grid voltage is high;
- c. switch the output line to the lower voltage phase if possible.

9.6.6.3 Circuit breaker trip during frog, cloudy and rainy day

check the resistance between PV(+) and ground, PV(-) and ground lower than 2MΩ.

9.6.6.4 Daily generation date cannot count from zero

check the date and time setting is correct.

9.7 Power Components Inspection(without DC power supply)

9.7.1 Power diode

- a. single diode







- b. dual-diode




Switch to the diode position of multimeter, please notice the '+' and '-'. The normal value is 0.33~0.37V('+' with '-'), ∞ ('-' with '+'). And specific value could compare with normal inverter. Value close to the zero or bigger than normal range stands the diode is damaged.

For the 5th generation models(total 4 measure positions)








9.7.2 IGBT / MOSFET

a. IGBT





b. MOSFET



- switch to the diode position of multimeter, and measure the value between Pin 3 and Pin 2, normal value is 0.3~0.4V. Value close to the zero stands the component is damaged;
- the normal resistance between Pin 2 and Pin 3 should be infinity(∞), value close to the zero stands the component is damaged;
- check if the short-circuit between Pin 1 and Pin 2, Pin 2 and Pin 3.

For the 5th generation models(total 8 measure positions)




9.7.3 Component Position Number

Power Diode Position Number
5th Generation Single MPPT
D1
5th Generation Dual-MPPT
D9, D13, D30, D31
IGBT/MOSFET Position Number
5th Generation Single MPPT
Q2, QA1, QA2, QA3, QB1, QB2, QB3
5th Generation Dual-MPPT
Q2, Q4, QA1, QA2, QA3, QB1, QB2, QB3

9.8 MOSFET Driver Inspection(for 5th generation models)

Remove the control board and control board mounting pad. Power the inverter with 100Vdc source and wait about 15 seconds. Measure the voltage of all of the MOSFET Pin 1 and Pin 3 separately, the normal driver voltage is -5Vdc. If the voltage abnormal, it stands the power PCB is damaged.



9.9 Inverter Frequently Tripping Due to Grid Fluctuation

9.9.1 Check the grid voltage with multimeter if voltage range goes below or beyond of -20% to +10% then check the Vac.Min and Vac.Max setting in inverter by selecting SET menu as mention below.

9.9.2 Press enter key for two time and menu is open which shows Error record (Fig.1)and by up-down key select the SET menu (Fig.2).



Fig.1



Fig. 2

9.9.3 Select the SET menu by enter key and you will get the display as mention in Fig. 3 and Fig. 4.



Fig.3



Fig.4

9.9.4 Press enter key to set the volatge range and enter the password as shown in Fig.5.



Fig. 5

9.9.5 Adjust the voltage range of Vac.Min and Vac.Max by up-down key and set it at Vac. Max:450V and Vac. Min:339V as shown in Fig.6 and Fig.7.



Fig.6



Fig.7

Note:- Display screen menu change according to rating of the Inverter.

10 Contact

Please do not hesitate to contact us for any technical problems you have. Please be sure to provide the following information in order to obtain necessary assistance:

- Inverter type
- Inverter serial number
- Inverter SN Number
- Customer Information

The contents of this manual are subject to change without further notice. For Rotosol latest product information, please visit our website www.rotosol.solar

Rotosol Solar(Division of Solar – Rotomag motors and controls pvt ltd.)

www.rotosol.solar

ADD: 2102/3 & 4 , Vitthal Udhyognagar

Near Anand, Gujarat – 388121 , India

Phone : +91-9227110023/24/25

E-MAIL: invert@rotosol.solar

Website : www.rotosol.solar

Annex Warranty Terms (Overseas)

Rotosol Solar(Division of Solar – Rotomag motors and controls pvt ltd.) Product Warranty Terms

1.Product Quality Standards and Warranty

1. Rotosol inverters comply with local safety regulations related to the national grid and grid standards.
2. The inverter warranty is decided by Rotosol and its distributor.
3. Spare parts warranty is valid 3 months (beginning from the date of shipment), during the warranty period, Rotosol is responsible for the replacement.

Spare Parts	
NO.	Item
1	DC PV Connector (MC4)
2	AC Connector
3	Fuse
4	Enclosure

The monitoring module warranty is valid for 12 months (beginning from the date of shipment). After the products leaving the factory, the appearance damage (scratches, rust, chemical damage) is beyond warranty.

2.Warranty Exceptions

Damage or lose to inverter or accessory caused by logistics.

Inverter failure caused by non-compliance with national utility grid standard which lead to eg. abnormal grid voltage, grid frequency etc.

Inverter malfunction or damage caused by non-professional or non-qualified personnel

Failure to observe the user manual, the installation guide, and the maintenance regulations

Remove or damage warranty seal

Change or remove specification label, serial number (SN)

Product malfunction or damage due to disobey to relevant laws and regulations or technical requirements in power plant design, construction or installation works

Solar panels' input parameters exceed the inverter's allowed range

Product malfunction or damage due to installation on movable device or in vibration occasions

Failure or damage caused by corrosion, lightning and other natural damage or force majeure

Unauthorized alteration or disassembly of the product

Damage or malfunction caused by other facilities eg. Surge damage caused by switching on/off high power generator

Low electricity generation because of inverter self-protection caused by environmental reasons (such as the installation environment, natural environment, grid environment, etc.) is not a quality problem.

3.Repair and Replacement

3.1 When a failure occurs, the user should check and record from the screen display the error code, DC voltage, AC voltage data or phenomena ect., then contact your local dealer.

When the dealer or Rotosol confirm that it is the product quality problem ,the faulty product will be replaced.

For the product has been replaced or repaired, the remaining warranty entitlement will be transferred to the replacement or repaired device

Rotosol is only responsible for the company's products troubleshooting, repair and replacement, but doesn't assume any other special damages, consequential damages, incidental damages (including loss of profits, loss of goodwill, loss of business reputation loss or delay, etc.).

This warranty does not affect the customer's enjoyment of any other rights laws and regulations relating to sales of consumer goods provided for in the host country or region.

4. Service Contact

Customers could contact local dealer or distributor to discuss how to proceed. Please visit www.rotosol.solar for dealer/installer's contact details. Of course, customers may also contact Rotosol if they need help or advice.

5. Force Majeure

Force majeure is not artificially unavoidable and insurmountable objective conditions. In addition, it is the loss that even if the use of methods of prevention and attention, cannot prevent. It includes the following:

- earthquakes, floods, fires, storms and other natural disasters.

- war, invasion, blockade and other hostile armed actors.

- revolution, rebellions, riots.

- strike.

- collection, prohibition, and other provisions of the government's actions.

- infectious diseases.

- third-party negligence and wrongdoing which Manufacturers cannot control

- h) others

6. For above, Rotosol will not bear any responsibility. Please be noted.



Rotosol Solar(Division of Solar – Rotomag motors and controls pvt ltd.)

www.rotosol.solar

ADD: 2102/3 & 4 , Vitthal Udhyognagar

Near Anand, Gujarat – 388121 , India

Phone : +91-9227110023/24/25

Customer Care Number : 1800-123-4412

E-MAIL: invert@rotosol.solar

Website : www.rotosol.solar